



**REF. 1455 MARINE PANEL
INSTALLER MANUAL**

FERMAX

INSTALLER MANUAL



CONGRATULATIONS FOR BUYING A QUALITY PRODUCT!

Fermax Electrónica develops and manufactures premium equipment that meets the highest design and technology standards. We hope you will enjoy all its functions.

Technical publication for information purposes edited by FERMAX ELECTRÓNICA S.A.U.

FERMAX ELECTRÓNICA applies a continuous improvement policy, therefore it reserves the right to modify the contents of this document, as well as the product features hereof at any time and without prior notice. Any modification will be reflected in subsequent editions of this document.

This product is protected with the following patents and utility models:

PATENTS: US 9215410, US 9762852, BE1023440, AU2014203706.

UTILITY MODELS: ES1187384U, ES1141495U, FR3038192, DE202016000632U1, CN205987229(U).

Cod. 970190I/V10_20


INDEX

1 DESCRIPTION	4
2 WEB BROWSER PROGRAMMING	5
2.1 DEVICE	6
2.2 GENERAL.....	7
2.3 NETWORK CONFIGURATION	10
2.4 ACCESS.....	11
2.5 FACE RECOGNITION.....	13
2.6 IP CAMERA.....	14
2.7 SIP	15
2.8 SIP TRUNK.....	17
2.9 SIP CALL	18
2.10 ADVANCED	20
2.11 PINCODE	23
2.12 QR ACCESS.....	23
2.13 RESTORE	24
2.14 LOG OUT	25
3 OPERATION	26
3.1 Icon functions.....	27
4 INSTALLATION.....	30
4.1 Flush box installation.....	30
4.2 Installation Guide Diagram.....	30
4.3 Connectors	31
4.4 Basic diagrams.....	32
4.5 Diagram Installation of the 4 RELAY MODULE REF. 1491	32
4.6 Diagram installation of the GUEST CODE Module Ref. 1494	33
4.7 Diagram installation of the lift control system Ref. 9545	33
5 TECHNICAL SPECIFICATIONS.....	34
6 ANNEX.....	35
6.1 Firmware updates	35
6.2 Regulations.....	36

1 DESCRIPTION

This document is the Installer Manual for MARINE PANEL REF. 1455, version V 02.10.

It includes installation and programming instructions.



NOTE:

Residents can access to their corresponding entrance by passing their authorized Mifare identifier. The door will open and release the lock.

The Mifare identifier data has to be added through FERMAX MEET MANAGEMENT software. Maximum 100.000 identifiers.


By means of their WIEGAND connection (output) it is possible to integrate this Mifare reader in third party Access Control Systems. It is also possible to integrate third party readers using WIEGAND protocol with the MARINE panel so the Wiegand output of the reader can be validated by the MARINE panel.

2 WEB BROWSER PROGRAMMING

For programming of the MARINE panel, access is required through a PC via a web browser. Preferably use Chrome browser.

The PC must be connected to the same LAN as the panel and configured with an IP address in the same range. The MARINE panel default IP address is 10.1.0.1.

Type the IP address of the panel in the address bar of the browser. An identification form will appear.



Sign in

http://10.1.0.1
Your connection to this site is not private


Username

Password

The default identification data are:

- **User name: admin**
- **Password: 123456**

A web page will appear with the different programming sections:



MEET VIDEO DOOR ENTRY SYST x +

← → ↻ ⌂ ⓘ Not secure | 10.1.0.1

FERMAX

MEET VIDEO DOOR ENTRY SYSTEM

DEVICE

GENERAL

NETWORK

ACCESS

FACIAL RECOG.

IP CAMERA

SIP

SIP TRUNK

SIP CALL

ADVANCED

PINCODE

QR ACCESS

RESET

LOG OUT

DEVICE INFO

FERMAX MARINE MEET PANEL
FIRMWARE: V02.10S
DEVICE: BLOCK PANEL 018-05
SERIAL NO.: 789A-36ED-5679
MAC: BC:F8:11:06:FC:53
IP: 10.200.200.72
COPYRIGHT © FERMAX ELECTRONICA S.A.U
www.fermax.com

**PROGRAMMING
SECTIONS**

2.1 DEVICE

The section DEVICE provides technical information regarding the equipment, as a reference.



FERMAX
MEET VIDEO DOOR ENTRY SYSTEM

DEVICE	DEVICE INFO
GENERAL	
NETWORK	
ACCESS	
FACIAL RECOG.	
IP CAMERA	
SIP	
SIP TRUNK	
SIP CALL	
ADVANCED	
PINCODE	
QR ACCESS	
RESET	
LOG OUT	

FERMAX MARINE MEET PANEL
FIRMWARE: V02.10S
DEVICE: BLOCK PANEL 018-05
SERIAL NO.: 789A-36ED-5679
MAC: BC:F8:11:06:FC:53
IP: 10.200.200.72
COPYRIGHT © FERMAX ELECTRONICA S.A.U
www.fermax.com

- **FERMAX MARINE PANEL:** Device type
- **FIRMWARE:** Version of the installed firmware
- **DEVICE:** Type and panel number
- **MAC:** Panel MAC number
- **IP:** IP address assigned to the-panel

2.2 GENERAL

The section GENERAL allows the configuration of the identification parameters of the **MARINE** panel within the installation.

It allows time and date configuration.

FERMAX
MEET VIDEO DOOR ENTRY SYSTEM

GENERAL SETTINGS

TYPE: BLOCK PANEL
BLOCK: 1
DEVICE NO.: 1
LANGUAGE: ENGLISH
PANEL VOLUME: 3
VOICE SYNTH.: ☒
VIDEO RESOLUTION: 640x480
SIP DIVERT MODE: PARALLEL CALL
CALL CONCIERGE: DIAL NUMBER TO CALL
CONCIERGE: 9901
SAVE

DATE FORMAT: DD/MM/YYYY
DATE: 01 / 03 / 2020
TIME: 10 : 43 : 21
TIME ZONE: GMT+01:00
DAYLIGHT SAVING: ☐
TIME:
SAVE

Button for saving options above of it

Button for saving date/time options only.

- **TYPE:** Select the identification parameters of the panel. There are some other parameters related, depending on TYPE selection:

GENERAL ENTRANCE PANEL

Panel installed in one of the main entrances to a condominium

TYPE: G.E. PANEL
DEVICE NO.: 1

- **DEVICE NUMBER:** Number assigned to the general entrance where this panel is installed (1-9000).
In the case that there is one entrance only, leave the default value 1.


BLOCK PANEL ENTRANCE

Panel installed in a single building or in a block of a condominium

TYPE:	BLOCK PANEL ▼
BLOCK:	1
DEVICE NO.:	1

- **BLOCK:** Number assigned to the block where the panel has been installed (1-999). In the case of 1 single block, leave the default value: 1.
- **DEVICE NUMBER:** Number assigned to the block entrance where this panel is installed (1-99). In the case that there is one entrance only, leave the default value: 1.

- **LANGUAGE:** Select the desired language in the dropdown options.



A dropdown menu for language selection. The menu is open, showing a list of languages. 'ENGLISH' is highlighted at the top. Below it are: 中文 (Chinese), ESPAÑOL (Spanish), РУССКИЙ (Russian), DEUTSCH (German), TÜRKÇE (Turkish), POLSKI (Polish), עברית (Hebrew), FRANÇAIS (French), فارسی (Persian), NEDERLANDS (Dutch), and PORTUGUÊS (Portuguese).

Default option is ENGLISH.

Refresh the webpage after changing the language.

- **PANEL VOLUME:** Select the desired value between 1 and 5. Default option is 4. The conversation volume is common for uplink and downlink.
- **VOICE SYNTH:** Enables or disables the speech when door lock is released. If the speech is disabled, no speech in the panel will sound when the lock is released.
- **VIDEO RESOLUTION:** In order to fit the different types of monitors. The default value 640×480
- **SIP DIVERT MODE:** This function is related to the SIP CALL function. Please refer to SIP CALL section for further details. The following options available:
 - **PARALLEL CALL:** When the panel calls the resident, the monitor and the MEET ME call divert APP will ring at the same time. Once a terminal answer, the call in the other terminals stop ringing.
 - **SEQUENTIAL CALL:** When the panel calls the resident, the monitor will ring 30s. If no answer, the call will be diverted to MEET ME APP or other associated devices.
- **CALL CONCIERGES:**
 - **DIAL BELL TO CALL:** The visitor presses directly bell button that will call the concierge.
 - **DIAL NUMBER TO CALL:** The visitor enters No. of concierge that show in the panel and press bell button will call the concierge.

- **NO CONCIERGE:** No concierge information in the display.
- **CONCIERGES:** The No.9901 to 9910 can be selected in the dropdown options, the selected concierge is available when the panel call concierge.
- **DATE FORMAT:** Format to show the date information in the screen.
- **DATE:** Setting date manually (See note below).
- **TIME:** Setting time manually (See note below).
- **TIME ZONE:** Setting the time zone of panel. Select local time zone and save.
- **DAYLIGHT SAVING TIME:** Shall be enabled for DST periods and disabled for winter time.

NOTES:

If the installation has **FERMAX MANAGEMENT SOFTWARE**, the date and time of panel will synchronize automatically with the management software. If the panel has access to Internet, the date and time of panel will also synchronize with internet time server.

If the installation has no **FERMAX MANAGEMENT SOFTWARE** the installer can set date, time and time zone manually. Do not use the GMT (TIME ZONE) adjustment in this case. GMT is usable only when the time is automatically taken from internet or **FERMAX MANAGEMENT SOFTWARE**.

Date and time cannot be saved after power loss, unless there were internet or management software in the installation. However, the time zone, date format and daylight-saving time can be saved anyway.

Pay attention to the **SAVE** button related to panel settings or date/time settings since are different and independent.

2.3 NETWORK CONFIGURATION

Allows the configuration of the different parameters of the LAN network

FERMAX
MEET VIDEO DOOR ENTRY SYSTEM

NETWORK SETTINGS

IP: 192.168.1.162
MASK: 255.255.255.0
GATEWAY: 192.168.1.1
DNS: 8.8.8.8
SOFTWARE IP: 192.168.1.200
SW. PIN: *****
SAVE

- **IP:** IP address to be assigned to this panel.
- **MASK:** Subnet mask corresponding to the LAN
- **GATEWAY:** LAN gateway
- **DNS:** DNS server address. In case of doubt, we recommend using the default value 8.8.8.8.
- **SOFTWARE IP:** IP address of the PC where the MEET Management Software is installed (if any).
- **SOFTWARE PIN:** PIN ACCESS code for the Management Software control. The default setting is 123456. Indicate the corresponding parameters and click SAVE to confirm.

NOTE:

The MEET system uses static IP addressing. This ensures that each device has a unique IP address in the same installation.

If a device has an IP address already assigned to another device on the network, an "IP CONFLICT" prompt will appear in the panel screen, along with the MAC of the conflicting device. Both devices will not work properly until this issue is resolved.

2.4 ACCESS

This section allows some programming related to the access control functionality of the panel.

The screenshot shows the 'ACCESS CONTROL SETTINGS' page of the FERMAX MEET VIDEO DOOR ENTRY SYSTEM. On the left is a vertical menu with options: DEVICE, GENERAL, NETWORK, ACCESS (highlighted), FACIAL RECOG., IP CAMERA, SIP, SIP TRUNK, SIP CALL, ADVANCED, PINCODE, QR ACCESS, RESET, and LOG OUT. The main settings area includes:

- DOOR RELAY TIME: 3s (dropdown)
- OPEN DOOR DELAY: 0s (dropdown)
- DOOR OPEN ALARM: DISABLE (dropdown)
- DOOR FORCED ALARM: ☐
- EXTERNAL RELEASE: ☐
- Four columns for additional relays (1#, 2#, 3#, 4#):
 - DOOR RELAY TIME: 1s (dropdown)
 - OPEN DOOR DELAY: 0s (dropdown)
- ADMIN. CARD: 123456 (text input)
- DISARM BY CARD: ☐
- GUEST CODE: ☐
- WIEGAND: BURST (dropdown)
- FACILITY: 100 (text input)
- ACCESS PIN: ☐
- Four PIN input fields: 0000, followed by three empty fields.
- A 'SAVE' button at the bottom.


- **DOOR RELAY TIME:** Time for lock-release relay remains active (1-9 s optional).
- **OPEN DOOR DELAY:** The time that the “open the door” command has been sent and the relay is not activated. The relay will active after the DOOR DELAY TIME be set. Open door relay is useful when the door is not near to the panel, the visitor has time to reach the door.(0-9s)
- **DOOR OPEN ALARM:** An alarm will trigger if the door is opened after the programmed DOOR ALARM time. Options: Disable, 30s, 60s, 120s, 180s and 250s.
- **DOOR FORCED ALARM:** An alarm will trigger if an abnormal way to open the door has been detected, for example because there has not been any previous “open the door” command.
- **EXTERNAL RELEASE:** Only available in panel programmed as PANEL 1. It activates or deactivates the additional relay performance.
A module Ref. 1491 (4 relay module) must be connected to the RS485 port of the panel No.1. See INSTALLATION section for further details.
 - **1-4 DOOR RELAY TIME:** Time that the corresponding additional door relay is active (1-9s optional).
 - **1-4 OPEN DOOR DELAY:** The time that the “open the door” command has been sent and the relay is not activated. The relay will be active after the DOOR DELAY TIME set. Open door delay is useful when the door is not near the panel. (0-9 s).

- **ADMIN CARD:** Admin/master card ID registered to enrol additional prox cards. This option is useful when there is not MEET MAGEMENT SOFTWARE available.
When there is no management software, enter 0000 if you do not know the ID of the admin card. The first MIFARE prox card detected by the reader will act as admin/master card.
The card of the residents can be added afterwards.
To program user cards, present the admin/master card previously created on the card reader. The panel will enter in cards program mode. All the cards presented from now on will automatically updated in the panel and may be used to open the door.
If there are not more cards to program, after two minutes the panel will exit program mode. There is not possible to deregister cards programmed by this method. Use the FERMAX MEET MANAGEMENT SOFTWARE for full operational possibilities.
- **DISARM BY CARD:** When an already programmed user card is presented to the reader, and it has been previously assigned to a monitor, the alarm system of the corresponding apartment will change to HOME mode.
- **GUEST CODE:** Guest code function can be enabled or disabled. The panel needs to be connected with a module Ref. 1494 GUEST CODE MODULE to a third-party Access Control System. See INSTALLATION section.
- **WIEGAND** Protocol used for Wiegand transmission through the REF.1494 GUEST CODE MODULE(BURST or 26 BITS). Enter available parameter depending on the third-party Access Control System
- **FACILITY:** Enter available parameter depending on the third-party Access Control System.
- **ACCESS PIN:** To enable or disable the activation of the relay for ACCES PIN code.
UP to 8 different PIN codes per panel. PIN length between 4 to 6 digits.

2.5 FACE RECOGNITION

Use this setting to enable or disable the FACE RECONGNITION function of the panel.

The FERMAX MANAGEMENT SOFTWARE V01.05 is required for programming and managing the photos of the authorized faces. System supports up to 6.000 faces



The screenshot displays the FERMAX web interface. At the top, there is a header with the FERMAX logo and the text 'MEET VIDEO DOOR ENTRY SYSTEM'. Below this is a navigation menu on the left with options: DEVICE, GENERAL, NETWORK, ACCESS, FACIAL RECOG. (highlighted), IP CAMERA, SIP, SIP TRUNK, SIP CALL, ADVANCED, PINCODE, QR ACCESS, RESET, and LOG OUT. The main content area is titled 'FACE RECOGNITION' and contains the following settings:

- FACE RECOGNITION: ☒
- MODEL: 5.0 (dropdown menu)
- LIVENESS DETECTION: ENABLED (dropdown menu)
- SIMILARITY: LOW (dropdown menu)
- A 'SAVE' button is located below the settings.

- **FACE RECOGNITION:** Enable or disabled face recognition function.
- **MODEL:** 5.0 in this version. Do not use MODEL 6.0, because it is prepared for future FERMAX MANAGEMENT SOFTWARE versions
- **LIVENESS DETECTION:** Enable or disabled LIVENESS DETECTION function.
- **SIMILARITY:** High, medium and low options. Default is low.

NOTES:

MEET panel face recognition function is based on a bidimensional face identification, with the ability of differentiating among photos or live faces in certain conditions.

This technology can be used to open doors but cannot guarantee the highest security level or 100% accuracy of liveness detection.

If face recognition is enabled, RTSP video streaming will not be available.

2.6 IP CAMERA

The monitor can switch to IP CCTV camera video during a conversation. This function allows to configure IP CCTV cameras using RTSP protocol to be displayed as an auxiliary camera to provide different view angles from the door or related areas

The screenshot shows the 'IP CAMERA SETTINGS' page of the FERMAX MEET VIDEO DOOR ENTRY SYSTEM. On the left is a vertical menu with options: DEVICE, GENERAL, NETWORK, ACCESS, FACIAL RECOG., IP CAMERA (selected), SIP, SIP TRUNK, SIP CALL, ADVANCED, PINCODE, QR ACCESS, RESET, and LOG OUT. The main content area is titled 'IP CAMERA SETTINGS' and contains the following fields:

- NUMBER OF CAMS: A dropdown menu set to '3'.
- IP CAM 1: A text field containing 'TENNIS COURT'.
- URL: A text field containing 'rtsp://admin:12345@192.168.1.72'.
- IP CAM 2: A text field containing 'CORRIDOR'.
- URL: A text field containing 'rtsp://admin:12345@192.168.1.174:554'.
- IP CAM 3: A text field containing 'LIFTS'.
- URL: A text field containing 'rtsp://admin:12345@192.168.1.44:554'.
- A 'SAVE' button at the bottom.


- NUMBER OF CAMS: Select up to 4 different cameras.
 - CAMERA 1, 2, 3 and 4: IP camera name.
 - URL: -> **rtsp://user:password@Ip_adress_of_camera** .
user:password -> for cameras that require a username and password for connection. Depending on the brand/model of camera, other URL different than the one above would be required. Check the IP camera technical documentation.

2.7 SIP

This option allows to configure MARINE panel to use SIP functionalities, such as smartphone divert using the FERMAX MEET ME APP or allows the panel to operate with a third-party SIP systems or terminals using SIP protocol instead of FERMAX MEET protocol.

Configuration for smartphone call divert, using FERMAX MEET ME APP

Configure the SIP parameters as explained below, if the divert function to smartphone, through the FERMAX MEET ME server is used.



The screenshot shows the FERMAX MEET VIDEO DOOR ENTRY SYSTEM interface. On the left is a vertical menu with options: DEVICE, GENERAL, NETWORK, ACCESS, FACIAL RECOG., IP CAMERA, SIP (highlighted), SIP TRUNK, SIP CALL, ADVANCED, PINCODE, QR ACCESS, RESET, and LOG OUT. The main area is titled 'SIP SETTINGS' and contains the following configuration fields:

ENABLE SIP:	<input checked="" type="checkbox"/>
SIP SERVER:	sip.sip.fermax.com
DOMAIN:	sip.fermax.com
OUTBOUND:	
STUN IP:	
STUN PORT:	0
H.264:	102
SIP USER:	0018796
SIP PASS:	*****
CONVERSATION:	120s
RING TIME:	35s

At the bottom of the settings area is a 'SAVE' button.

- **ENABLE SIP:** Select this box to enable SIP functions.
- **SIP SERVER:** Use the FERMAX MEET server -> **sip: sip.fermax.com**
- **DOMAIN:** Indicate the server domain -> **sip.fermax.com**
- **OUTBOUND:** Not necessary. Leave it in blank.
- **STUN IP:** Not necessary. Leave it in blank.
- **STUN PORT:** Not necessary. Leave it in blank.
- **H.264:** Leave the default value: 102
- **SIP USER, SIP PASSWORD:** Indicate the user and password of the FERMAX MEET ME license assigned to this panel. They are indicated in a label attached in the front of the panel.
- **CONVERSATION, RING TIME:** No function.

Configuration for SIP server integration

Configure the SIP parameters as explained below, for the cases where the MARINE panel works as an extension of a SIP server.

Contact with the SIP server administrator to get some of the information required in this section.



The screenshot shows the FERMAX web interface. At the top, there is a banner with the FERMAX logo and the text "MEET VIDEO DOOR ENTRY SYSTEM". Below the banner is a sidebar menu with the following items: DEVICE, GENERAL, NETWORK, ACCESS, FACIAL RECOG., IP CAMERA, SIP (highlighted), SIP TRUNK, SIP CALL, ADVANCED, PINCODE, QR ACCESS, RESET, and LOG OUT. The main content area is titled "SIP SETTINGS" and contains the following configuration fields:

ENABLE SIP:	<input checked="" type="checkbox"/>
SIP SERVER:	sip:192.168.1.190
DOMAIN:	192.168.1.190
OUTBOUND:	sip:
STUN IP:	192.168.1.190
STUN PORT:	5060
H.264:	102
SIP USER:	1012
SIP PASS:	*****
CONVERSATION:	120s
RING TIME:	35s

At the bottom of the settings area is a "SAVE" button.

- **ENABLE SIP:** Select this box to enable SIP functions.
- **SIP SERVER:** Indicate the sip SERVER address. Format -> **sip: IP_SERVER**
- **DOMAIN:** domain of the SIP server or IP address
- **OUTBOUND:** Not necessary. Leave it in blank.
- **STUN IP:** domain of the SIP server
- **STUN PORT:** Used for the configuration of Internet SIP server-based installations. It is usually port 5060. Check with your network or SIP server administrator.
- **H.264:** Depends on the SIP SERVER. In the case of doubt, leave the default value.
- **SIP USER, SIP PASSWORD:** Indicate the user and password that this terminal is programmed in the SIP server.
- **CONVERSATION, RING TIME:** No function.

2.8 SIP TRUNK

When there is a VoIP gateway installed on the network connected to a PSTN line or cloud SIP TRUNK SERVER.

The panel call can be diverted to user's mobile phone or land line telephone through a voice gateway.

FERMAX
MEET VIDEO DOOR ENTRY SYSTEM

SIP TRUNK SETTINGS

DEVICE
GENERAL
NETWORK
ACCESS
FACIAL RECOG.
IP CAMERA
SIP
SIP TRUNK
SIP CALL
ADVANCED
PINCODE
QR ACCESS
RESET
LOG OUT

ENABLE SIP TRUNK: ☐
URL:
SAVE

ENABLE SIP TRUNK: Enable or disable SIP trunk function.

URL: URL of the device:

Format

sip: sip_trunk_account @sip_trunk_domain: port

or

sip: sip_trunk_account@sip_trunk_ip:port

2.9 SIP CALL

This option allows to generate calls to smartphone devices in the cases where it is not a MEET monitor associated in the installation. A FERMAX MEET ME licence Ref. 1496 is required for each apartment. The call can be received, simultaneously, in 8 smartphones in the same apartment.

Furthermore, it is also possible, to generate simultaneous calls to several devices MEET and/or third-party SIP devices as well, using SIP protocol instead of FERMAX MEET protocol.

A .CSV file containing the associated number and the information of the diverted device or devices must be updated in the panel.

The screenshot shows the FERMAX MEET VIDEO DOOR ENTRY SYSTEM interface. On the left is a vertical menu with options: DEVICE, GENERAL, NETWORK, ACCESS, FACIAL RECOG., IP CAMERA, SIP, SIP TRUNK, SIP CALL (highlighted), ADVANCED, PINCODE, QR ACCESS, RESET, and LOG OUT. The main area is titled 'SIP CALL SETTINGS'. It contains a file selection area with 'Choose file' and 'No file chosen' buttons, and 'IMPORT' and 'EXPORT' buttons. Below this is a table with columns 'APARTMENT' and 'NUMBER', repeated three times. The table is currently empty.

The operation procedure to generate and update the .CSV file is as follow:

1. Select EXPORT to generate a blank .CSV table, an save it in your PC. Rename this table as your choice or leave the default name (MEET CALL DIVERT PXXX-YY.csv), where XXX is the BLOCK NUMBER and YY is the device number assigned to this panel).
2. Use Microsoft Excel to open the created file. It will look like:

The screenshot shows a Microsoft Excel spreadsheet. The columns are labeled A, B, C, D, and E. The rows are numbered 1 through 15. The first row (row 1) has the text 'APARTMENT,NAME,' in column A. The rest of the table is empty. The status bar at the bottom shows 'Ready' and the file name 'MEET CALL DIVERT P001-01 (1)'.

3. The first cell (A1) has the content: APARTMENT, NAME,
Do not change it.
4. Use the following cells (A2, A3, A4, etc.) to fill in the data of the devices to divert.
Depending on the type of call, the format of the data is different:
 - a. In the case of a call to a FERMAX MEET ME LICENCE:
APARTMENT, sip: XXXXXXX@sip.fermax.com where XXXXXXX is the licence username and APARTMENT is the number to be dialled in the panel
 - b. In the case of a call to a MEET device in the same installation:
APARTMENT, sip:XXX@IP_DEVICE where XXX is any identifier of the device and IP_DEVICE is the IP address to the MEET monitor to call.
 - c. In the case of a call to a third party SIP device (through a SIP server):
APARTMENT, sip:user@IP_SIP_SERVER where user is the identification user that the called device has been programmed in the SIP server, and IP_SIP_SERVER is the SIP server IP address.
 - d. It is also possible to assign multiple and different divert formats to the same apartment (for example a call to a third-party SIP device and a smartphone device as well).
Use the corresponding format explained above, using the same row but different column for each format. **See example below.**
5. Once the table has been finished, save it and import to the panel. For this, click on “Choose file”, select the file to import and click on IMPORT button.
Wait for a few seconds until a pop-up message “UPLOAD SUCCESSFUL” appears.

EXAMPLE

	A	B	C	D
1	APARTMENT,NUMBER,			
2	170,sip:170@192.168.1.190			
3	171,sip:0103283@sip.fermax.com			
4	645,sip:645@192.168.1.195			
5	180,sip:1234@192.168.1.170			
6	181,sip:1234@192.168.1.170	sip:0103283@sip.fermax.com		
7	182,sip:1234@192.168.1.170	sip:170@192.168.1.195		
8	183,sip:1234@192.168.1.170	sip:172@192.168.1.197	sip:0103283@sip.fermax.com	
9				
10				
11				
12				
13				
14				

In this example:

- Apartment 170 generates a call to the monitor IP 192.168.1.190 in the same installation.
- Apartment 171 generates a call to the smartphone with FERMAX MEET ME licence 0103283.
- Apartment 645 generates a call to the monitor IP 192.168.1.195 in the same installation.

- Apartment 180 generates a call to the SIP device 1234 of the SIP server with IP 192.168.1.170.
- Apartment 181 generates a call to the SIP device 1234 of the SIP server with IP 192.168.1.170 and to the smartphone with FERMAX MEET ME licence 0103283.
- Apartment 182 generates a call to the SIP device 1234 of the SIP server with IP 192.168.1.170 and to the monitor IP 192.168.1.195 in the installation.
- Apartment 183 generates a call to the SIP device 1234 of the SIP server with IP 192.168.1.170 and to the monitor IP 192.168.1.197 in the installation and to the smartphone with FERMAX MEET ME licence 0103283.

2.10 ADVANCED

Some advanced settings, such as quick dial and directory, can be selected in this section.

- **QUICK DIAL:** No function
- **URL:** No function
- **ONU (GPON):** Used in large installations based on SIP protocol (GPON) and in combination with the configuration of said installations.
- **DIRECTORY:** MARINE panel allows to use a directory for calling the tenants. Visitors can select the tenant name from this directory and call directly without knowing the apartment number.
-

A .CSV table with the name of the tenants and apartment numbers shall be created.

The operation procedure to generate and update the .CSV file is as follow:

1. Select EXPORT to generate a blank .CSV table, an save it in your PC.
Rename this table as you wish or leave the default name *agenda.csv*.

2. Use Microsoft Excel to open the created file. It will have a look like that

	A	B	C	D	E
1	APARTMENT,NAME,				
2					
3					
4					
5					
6					
7					
8					
9					
10					
11					
12					
13					
14					
15					

3. The first cell (A1) has the content: APARTMENT, NAME,
Do not change it.
 4. Use the following cells (A2, A3, A4, etc.) to fill in the data of apartment name ad user's name, with the format **"Apartment_number", "Name"**,
 5. Once the table has been finished, save it and import to the panel. For this, click on "Choose file", select the file to import and click on IMPORT button.
Wait for a few seconds until a pop-up message "UPLOAD SUCESSFUL" appears.
- **RESIDENT SEARCH:** The visitor can quickly search tenants via shortcut if the function is enabled.

2020/01/01 08:00

①	A	B	C	D		
②	E	F	G	H		
③	I	J	K	L		
④	M	N	O	P		
⑤	Q	R	S	T		
⑥	U	V	W	X	Y	Z

ⓐ ×
Search
ⓑ ✓

EXAMPLE

	A	B
1	APARTMENT,NAME,	
2	201,Abel Shelton,	
3	202,Albert Reed,	
4	301,Fernando Magister,	
5	302,James Merlo,	
6	601,Juan GHolley,	
7	602,Tom Fucci,	
8		
9		
10		
11		
12		
13		
14		
15		
16		
17		
18		
19		

2020/01/01 08:00	
Abel Shelton	201
Albert Reed	202
Fernando Magister	301
James Merlo	302
Juan Holley	601
Tom Fucci	602
Ⓐ × 🔔 Call	

NOTE:


In the case of non-Latin alphabets (for example: Chinese, Russian / Cyrillic, Arabic, Hebrew etc.), the procedure is as follows:

1. From the web server of the panel, export the empty .CSV file.
2. Open with Windows Notepad and copy the directory list of the CSV file in the notepad with the desired alphabet (Latin, Chinese, Russian / Cyrillic, Arabic, ...).
3. Save the file as .CSV / all files *. * / UTF-8
4. From the panel's webserver, import this file and wait for the message "file uploaded successfully" to be displayed.

In the case of non-Latin writing systems, it is recommended NOT to use Microsoft Excel since there is a risk of altering the format of the directory file and that the content of the directory is not loaded correctly

2.11 PINCODE

It allows you to change the INSTALLER PIN code, to access both the installation configuration parameters through the monitor's own screen and the configuration through a web browser.



The screenshot displays the FERMAX web interface. At the top, there is a header with the FERMAX logo and the text "MEET VIDEO DOOR ENTRY SYSTEM". Below the header, a sidebar on the left contains a list of menu items: DEVICE, GENERAL, NETWORK, ACCESS, FACIAL RECOG., IP CAMERA, SIP, SIP TRUNK, SIP CALL, ADVANCED, PINCODE (which is highlighted), QR ACCESS, RESET, and LOG OUT. The main content area is titled "PINCODE SETTINGS" and contains three input fields labeled "CURRENT PIN:", "NEW PIN:", and "CONFIRM PIN:". A "SAVE" button is located below these fields.

Enter the current code, the new pin and confirm it.

The new password can have alphanumeric characters and has no limit on its length.

Finally, select SAVE.

NOTE:

Make a note of the new PIN at your convenience. If you lose or forget your PIN, you should contact FERMAX's Technical Department to receive instructions regarding its recovery. All settings programmed into the monitor will be lost after recovery.

2.12 QR ACCESS

This function is not available in this version of Firmware V 02.10. It is recommended to deactivate it in the web server so that the icon does not appear in the lower part of the screen of the MARINE

2.13 RESTORE

Use this functionality to remotely reset the MARINE panel, or to return it to factory settings. In both cases it will ask for confirmation.



RESTORE FACTORY SETTINGS: The panel will automatically turn off and start up with the factory settings. We refer below the essential default parameters for your reference.

GENERAL

- BLOCK: 1
- DEVICE: 1
- LANGUAGE: ENGLISH
- VIDEO RESOLUTION: 640 x 480
- INSTALLER PASSWORD: 123456

NETWORK

- IP: 10.1.0.1
- MASK: 255.0.0.0
- GATEWAY: 10.254.0.1
- DNS: 8.8.8.8
- SOFTWARE IP: 10.0.0.200


Any other parameters (sip, IP cameras, concierges, etc.) that have been configured will also be lost.

- **REBOOT DEVICE:** The panel will automatically turn off and start up keeping all the programming parameters.

When resetting, the device will lose connection with the PC. Refresh the website after about 60 seconds to resume the connection.

2.14 LOG OUT

Use this functionality if you want to end your working session with this panel



The panel will request access credentials again in the case of new access via web server

3 OPERATION

The screen of the MARINE PANEL is interactive, so its performance depends on the call process or selected function.

When someone stands in front of the panel or press button, a standby interface is shown. This standby interface loop playback, depending on the programming settings.



It is also possible to select one of the available function icons via shortcut or menu. These icons have to be enabled by the installer.

See WEB BROWSER PROGRAMMING section for further details.

NUMERICAL KEYPAD


Apartments can be called only with numbers.

To call an apartment, dial apartment number and press the bell button.

It is also possible to enter shortcut button or access menu and use the available icon functions (access code, face recognition, etc.), enter AA to enter face recognition, enter A0 to enter access code, enter A7 to enter guest code, enter A8 to directory.

ON SCREEN INFORMATION

It is possible to get basic information on the equipment configuration through the screen



1. Dial 9999,
followed by B button

2. The screen will display information
about panel settings:

26

- Firmware version
- General settings
- Serial number
- MAC
- IP address

STANDBY

If the keypad is not used and nobody is in front of the panel, the display turns off after 1 minute for energy saving.

3.1 Icon functions

Depending on the programming and capabilities of the installation, some icon functions will be available in the menu.



Up to 4 icons will appear on the screen. If there were more than 4 functions available, use the arrow button to make visible the hidden ones.

The utility of each icon is explained below. Select the corresponding icon and press B button to use the associated function.



FACE RECOGNITION icon

Users can be identified by means of facial recognition.

Press arrow button and access to menu, select this icon via arrow button, then press "B". Alternatively press AA when the panel is standby. The face recognition interface will appear.

Users should stay for a few seconds in front of the panel.

If the user's face has been programmed and the system recognises him, the door will open.



NOTE:

Face recognition requires previous programming by means of the FERMAX MEET MANAGEMENT Software.



DIRECTORY icon

It allows to use a directory for selecting and calling an apartment searching the owner's name. Press arrow button and access to menu, select this icon via arrow button, then press "B". Alternatively press A8 when the panel is standby. The agenda interface will appear. Select apartment via arrow button, then press bell button.

2020/01/01 08:00	
Abel Shelton	201
Albert Reed	202
Fernando Magister	301
James Merlo	302
Juan Holley	601
Tom Fucci	602
Ⓐ × 🔔 Call	

It is possible to search a name, press the number which contain the initial character and it will filter the names which their first character matches.

2020/01/01 08:00	
①	A B C D
②	E F G H
③	I J K L
④	M N O P
⑤	Q R S T
⑥	U V W X Y Z
Ⓐ × Search Ⓑ ✓	

A programming is required. See WEB BROWSER PROGRAMMING section for further details.




GUEST CODE icon

This option allows users to open the door by means of entering a PIN code that has been provided to him, for example to get access during a certain day.

Press arrow button and access to menu, select this icon via arrow button, then press “B”, or press “A7” when the panel is standby, the Guest Code interface will appear, users shall enter the valid guest code followed by “B” to open the door.

If a wrong code is entered the panel will show an INVALID CODE message.



The panel shall have installed a GUEST CODE MODULE Ref.1494, as explained in the INSTALLATION section. A third-party Access Control System is required.




ACCESS PIN icon

This option allows users to open the door by means of entering an access code. Length of the access code could be between 4 to 6 digits.

The panel admits up to 8 different access codes, that must be programmed by the installer.

Press arrow button and access to menu, select this icon via arrow button, then press “B”, or press “A0” when the panel is standby, the Access code interface will appear. Users shall enter the valid Access code followed by “B” button to open the door.


If a wrong code is entered the panel will show an INVALID CODE message




See WEB BROWSER PROGRAMMING section for further details.

4 INSTALLATION


4.1 Flush box installation



4.2 Installation Guide Diagram




1. Flush box install.



2. fix the six screws.

4.3 Connectors

The MARINE panel is connected to the installation by means of connectors: Ethernet for LAN connection and MOLEX type connectors for other connections (power supply, RS-485, etc.). A bag containing the corresponding female connectors with their cables comes with the panel.



POWER INPUT: 12 Vdc power supply for the cases where no LAN PoE is available.

OUTPUT: Electric lock control relay output.

- NC: Normally closed contact
- NO: Normally opened contact
- C: Common

NOTE: NC & C contacts are internally duplicated

EX PROXIMITY (external proximity reader)

- (WD0-WD1) Wiegand input/output
- (+5V, -) 5 Vdc auxiliar output

Exit Button / Fire / Door Sensor. See NOTES.

- (EXIT, -) Connections for indoor button
- (F, -) Input for fire alarm & block doors unlock contacts
- (DS, -) Connection for door opened sensor

RS485

- Output for Ref. 1491/Ref. 9545 MEET LIFT Control Gateway, Ref. 1494 Guest code or Ref. 1490 External Relay (*)

(*) Ref. 1490 works as an auxiliar relay in parallel with the panel's relay.

RJ 45 Network

- RJ-45 LAN or LAN PoE connection

NOTES

EXIT, FIRE and DS require installer programming. See WEB BROWSER PRORAMMING for further details

EXIT button allows users to open the door from inside.

FIRE input in PANEL No 1 has to be connected to a fire output relay of a third-party fire alarm system. If a fire alarm is triggered, an alarm will sound in all the panels of the block, and all the doors will remain opened.


Installing a door open sensor in DS, an alarm sounds in the panel and concierge if the door remains opened during a programmed period, or the door has been forced as well.

The panel has an internal tamper button. If the panel is separated from the wall, an alarm is triggered in the panel, concierge and FERMAX MANAGENEMN SYSTEM (if exists).

4.4 Basic diagrams

Basic diagram using PoE Switch.


Use a power supply adapted to the electric lock voltage & current



Basic diagram using no PoE switch


Supply the panel by means of a FERMAX Ref. 4813 (12 Vdc 2A) power supply

Use a power supply adapted to the electric lock voltage & current. Do not power the panel and the electric lock from the same power supply.




4.5 Diagram Installation of the 4 RELAY MODULE REF. 1491

This module is necessary if you want to use the function of activating from the monitors additional relays (up to 4), for example to activate additional doors or gates.




The 1491 module need be connected to the PANEL No.1 in the block.

4.6 Diagram installation of the GUEST CODE Module Ref. 1494



4.7 Diagram installation of the lift control system Ref. 9545



This installation has to be performed in the PANEL no. 1 of the corresponding block only.

5 TECHNICAL SPECIFICATIONS

Power supply: 12 Vdc or PoE

Standby current (max.) : 290 mA

Working current (max.): 490 mA

- **Display specifications**
 - Size: 4.3 inch
 - Format: 4:3
 - Resolution: 480x 272
- **Camera specifications**
 - Resolution: 1280(H) x 720(V)
 - Visual angle: 128°(H) , 70° (V),
 - Minimum illumination: 0.5Lux
- **Maximum conversation time: 120s**
- **Door relay time: 1-9s**
- **Door delay time: 0-9s**
- **Door sensor time: 120s**
- **IC cards: 100,000 cards**
- **Face data: 6.000 faces**
- **Operating temperature: -40~70 °C**
- **Relative humidity: 20%~80%, without condensation**

6 ANNEX

6.1 Firmware updates


Sometimes it may be necessary or convenient to update a new firmware version because improvements or corrections have been incorporated into its operation.

FERMAX's Technical Department periodically informs (through Communications, Technical Bulletins, etc.) about the release of a new firmware update, as well as the improvements incorporated. Contact the FERMAX Technical Department if you wish to receive the corresponding update file.

The firmware update is performed via the **MEET System Upgraded Tool V 1.2.exe**. The procedure for updating the firmware with the corresponding update file is as follows.

It is possible to update several panels at the same time, selecting the range of the corresponding IP addresses (all of them have to be sequential).

1. Start the **MEET System Upgraded Tool V 1.2.exe**.



2. Click on “...” button and browse the PC to find the corresponding .IMG update file.
Up to 3 .IMG files can be selected at the same time (for the case of the update has more than unique .IMG file).
3. Indicate the IP Range of the panels.
4. Select Upgrade.

The new firmware will be installed, and the monitor will automatically restart.

6.2 Regulations

RADIO FREQUENCY MODULE. EC DECLARATION OF CONFORMITY:

FERMAX ELECTRÓNICA, S.A.U. declares that this product complies with the requirements in the RED 2014/53/EU Directive “Radio frequency equipment”.

<https://www.fermax.com/intl/en/pro/documents/technical-documentation/DT-13-declarations-of-conformity.html>

Radio frequency module:

- Frequency: **13.56MHz** / Maximum Power: **2,45mW**.

This device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

